

# Canon HD Camcorder Firmware Update Procedure

## *XF205/XF200*



Firmware is software installed to control the equipment. Using the firmware, the camcorder can perform many operations, such as shooting or processing the image. The following is an explanation of how to update your camcorder to the new firmware.

Please note that, the following items are required to perform this update, so please have them ready in advance.

- 1) Computer
- 2) Commercially available SD/SDHC/SDXC memory card (64 MB or more)
- 3) Commercially available SD card reader or SD card slot built into the computer

Make sure you have read the precautions and procedures below carefully before updating the firmware.

### **IMPORTANT: Observe the following precautions when updating the firmware**

- When updating the firmware, make sure to use a battery pack and power the camcorder using the supplied compact power adapter.
- Before updating the firmware, initialize the SD card in the camcorder. When you initialize the SD card, any data written on it will be erased. Therefore please be sure to save a copy of any important data on your computer or some other media prior to initializing it.
- While updating the firmware, make absolutely sure not to turn the camcorder off or to operate its buttons or controls. Doing so could cause camcorder malfunctions.
- After the firmware update is completed, all of the camcorder settings are reset to their default values.
- After the firmware update is completed, it is not possible to revert back to a previous version.
- If the firmware update does not finish normally, or if the camcorder no longer starts normally, please contact our customer support center.

## Step 1: Make Preparations


The following items are required for this firmware update.

1.	Camcorder	XF205 or XF200
2.	Computer	OS: Computer running either Windows or Mac OS <sup>(*)</sup>
3.	Memory card	A 64 MB or higher-capacity SD/SDHC/SDXC memory card (both commercially available)
4.	Memory card reader/writer	An SD card reader (commercially available) or an SD card slot built into the computer
5.	Battery Pack	The battery pack (BP-955) that comes with the camcorder
6.	Compact Power Adapter (AC Adapter)	The compact power adapter (CA-930) and DC cable (DC-930) that come with the camcorder


<sup>(\*)</sup> OS Requirements: Windows 8.1, Windows 8, Windows 7 SP1, or Mac OS X (10.7-10.10)


## Step 2: Check the firmware version on your camcorder

1. Connect the compact power adapter (AC Adapter) and DC cable to the camcorder, and insert the battery pack into the camcorder.




- (1) Hold down the button on the POWER switch and move it to OFF.
- (2) Connect the DC cable to the DC IN terminal on the camcorder.
- (3) Connect the power cord to the compact power adapter (AC Adapter) and plug it into a power outlet.
- (4) Connect the DC cable to the compact power adapter (AC Adapter).
- (5) Insert the battery pack.



2. Slide the POWER switch to CAMERA.
3. Press the MENU, and open the [Firmware] submenu.  
[  Other Functions ] -> [Firmware]

Firmware Version 1.0.3.0 is for camcorders with Firmware up to Version 1.0.0.xx - 1.0.2.xx. If the camcorder's firmware is already Version 1.0.3.xx, it is not necessary to update the firmware.



4. Press the MENU, and slide the POWER switch to OFF.

### Step 3: Prepare an SD card for the firmware update

First, insert an SD card into the camcorder and initialize it. This section will explain how to use your computer and an SD card reader (or an SD card slot built into the computer) to copy the new firmware to the initialized SD card.

#### Caution

**When you initialize the SD card, all of the data saved on it will be erased, so make sure to save any important data on your computer or somewhere else before initializing the SD card. If you perform the firmware update with data remaining on the SD card, it could cause the camcorder to malfunction.**

#### Insert the SD card into the camcorder and initialize it.

1. Insert the SD card into SD card slot on the camcorder.
2. Slide the power switch to CAMERA.
3. Press the MENU, and open the [Initialize Media] submenu.

[  Other Functions ] -> [Initialize Media]

4. Select [SD Card] and then press the SET.
5. Select [Complete] and then press the SET.



6. Select the [OK] and then press the SET. The initialization will start, and after a short while, the process will be completed and a confirmation screen will appear. Press the SET.



7. Press the MENU, and slide the power switch to OFF, and then remove the SD card from the camcorder.

**Next you will use a computer to copy the firmware to the SD card that was completely initialized in the camcorder. Make sure to perform the procedure that corresponds to your computer's operating system (Windows or Mac OS).**

## For Windows

1. Insert the completely initialized SD card into an SD card reader (or an SD card slot built into the computer).
2. If you click on the **Computer** icon, a removable disk icon labeled **CANON** appears.
3. Drag the firmware update data **VKC3.FIM** from the **xf205-v1030-win** folder created previously to the **CANON** icon.

### Caution

**Please be sure to copy the firmware to the root directory of the SD card.**

4. After copying the data, double-click the **CANON** icon. If you see the file **VKC3.FIM**, the copying process is completed.

## For Mac OS

1. Insert the completely initialized SD card into an SD card reader (or an SD card slot built into the computer), and an icon labeled **CANON** will appear on the computer's desktop.
2. Drag the firmware update data **VKC3.FIM** from the **xf205-v1030-mac** icon created previously to the **CANON** icon on the desktop.


### Caution


**Please be sure to copy the firmware to the root directory of the SD card.**

3. After copying the data, double-click the **CANON** icon. If you see the file **VKC3.FIM**, the copying process is completed.

## Step 4: Update the camcorder to the new firmware

This section explains how to operate the camcorder.


1. Connect the compact power adapter (AC Adapter) and DC cable to the camcorder, and insert the battery pack into the camcorder. (Refer to the Step2-1)
2. Insert the SD card that contains the firmware update data into the SD card slot of the camcorder.
3. Slide the POWER switch to CAMERA.
4. Press the MENU, and in the submenu of [  Other Functions], select [Firmware], and then press the SET.
5. When the firmware update confirmation screen appears, select [OK] and then press the SET button to start the firmware update. After a short while (approximately 10 minutes.), the firmware will be updated.



### Caution

The firmware update takes approximately 10 minutes to complete. During this time, please do not turn off the camcorder or operate any of its controls. Doing so could cause camcorder malfunctions.

6. After the update ends, the camcorder will automatically restart, and a screen that shows the new firmware version will appear. Press the SET.



7. All of the settings will be reset, and the [Date/Time] screen will appear. Set the date and time.
8. Perform the steps in **“Step 2: Check the firmware version on your camcorder”**, to confirm that the firmware version has changed.
9. Turn off the camcorder, and then remove the SD card.

**The firmware update is complete.**

### Caution

After the firmware update is completed, make sure to follow steps 1 to 7 of **“Step 3: Prepare an SD card for the firmware update”** completely initialize the SD card that was used to copy the firmware before using the SD card. Also, make sure to delete the firmware you downloaded from your computer.