

Phottix Indra Studio light PC firmware update manual

Before you begin

1. Firmware upgrades will be announced at <http://journal.phottix.com> and download link will be provided.
2. Unzip the firmware archive and save to your computer.
3. The archive will contain three files, download-fds.exe (the upgrade software) an .fds file and) a .fif file (latest firmware and icon file) and instructions and notes on the upgrade.
4. The Indra does not need to be connected to its battery to upgrade the firmware.

Checking the firmware version number

To check the current version of the firmware of your Phottix Indra studio light.

1. Open the folder containing the upgrade.
2. Double click on download.fds.exe. This will start the upgrade software (see image below)



3. Connect the mini USB cable between the Indra to the computer.
4. The computer will detect a new removable storage device connected (FDT11TA V01), at the same time the computer will show the logo.
5. Click the "Version" icon to check the current firmware version of your Phottix Indra. (see image below)



6. Upon completion safely remove USB hardware and disconnect the USB cable. Properly close/exit the USB device on your computer before disconnecting the USB cable.




Update Phottix Indra studio light firmware


1. Open the folder containing the upgrade.
2. Double click on download.fds.exe. This will start the upgrade software. (as with image below)



3. Connect the mini USB cable between the Indra to the computer.
4. The computer will detect a new removable storage device connected (FDT11TA V01), at the same time the computer will show the logo.
5. To update the firmware, click the "Software" icon, In the Window file selection dialogue box double-click the firmware file located in the same folder as the software (with .fds extension). The screen will show progress bar to indicate the update process. (see image below)



6. To update the icon database, click the Icon image. double-click the .FIF upgrade from the upgrade archive folder. The status of the upgrade will be displayed in the progress bar. (see image below)



7. Upon completion, the update software will indicate 'Update OK' (see image below), The Indra LCD will indicate 'update OK' ;



8. Upon completion safely remove USB hardware and disconnect the USB cable. Properly close/exit the USB device on your computer before disconnecting the USB cable.

Please Note :

- Certain anti-virus application may cause a warning dialogue box to appear when attempting to run the "Phottix Mitros PC Upgrade.EXE" application. If this happens click "allow this program to run".
- Treat the Phottix Indra as you would a USB flash drive. Please properly close/exit the USB device on your computer before disconnecting the USB cable.